



UPDATED  
VERSION  
NOV 2009

## PRODUCT INSTALLATION INSTRUCTIONS

### CIXX WALL MOUNTED VOLUME CONTROLS AND DIVERTERS



COMPLETE TRIM



CX-WM-1/2VC



CX-WM-3/4VC



CX-WM-DIV4

### Installation:

It is strongly advised to employ a professional plumber when installing this faucet.

1. The valves may be placed anywhere, depending on the home owner's preference and local plumbing code.
2. Drill 1" holes for the valve stems  
(The 1-3/4" escutcheon will cover any gap between the valve stems and the holes)
3. Separate the Valves from the Trim:
  - a. Unscrew the escutcheon from the valve stem and remove the handle. Do not loose the valve stem extension.
4. Valves should be installed with 1-11/16" protruding from the finished wall to the end of the of the inner valve stem exposed. Better to be too far out than too short; these can be cut back up to another 1". The outer threaded sleeve must have at least 1/4" exposed from finished wall.
5. Installing the trim:
  - a. Slide the valve stem extension onto the end of the valve stem and thread the escutcheon.
  - b. Before the stem exits the top of the escutcheon, insert the handle into the hole on the end.
  - c. Finish threading the escutcheon onto the valve stem, seating the handle in place.
6. If it feels like there is binding when the stem extension engages the handle, carefully back it off and try again. If installed improperly, the handle will wobble and the stem may break when used.