



Version 12 2007

WATERBRIDGE DECK MOUNT LAV LEG EXTENSIONS INSTALLATION INSTRUCTIONS

This Accessory adjusts the overall height depending on the vessel you are using it with.

Included in kit:

- Qty 2 - Leg Extensions
- Qty 2 - 24" supply lines

Supplies and tools needed:

- Soft cloth or towel
- 7/16" Wrench

Step 1:

Remove the two brass retaining nuts and two trim rings.

Step 2:

Remove both legs from the "H-Body" by turning counter-clockwise. Set aside on cloth.

Step 3:

With the 7/16" Wrench, remove the 14" supply lines and set aside.





Version 12 2007

Step 4:

Install the 24" supply lines that came with your kit. Hand tighten first, then using the 7/16" wrench tighten an additional 1/4 turn.

Step 5:

Re-install the legs into the "H-Body" by turning clockwise.

Step 6:

Install the leg extensions onto the brass 'all-thread'.

NOTE:

This is where you will make the height adjustment according to local plumbing code and sink height.





Version 12 2007

Step 7:

Slip the trim rings back onto the 'all-thread' prior to placing into holes drilled in counter.

Step 8:

After the installation is complete, put a level across the handles and adjust the leg extensions as necessary to achieve a balanced height and ensure proper water flow.

