



UPDATED
VERSION
JAN 2007

INSTALLATION INSTRUCTIONS C i X X SERIES – SHOWER HEAD



Parts and tools included: 1-CIXX Shower Arm, 1 CIXX Shower Head,
2 Allen Wrenches (four set screws)

Supplies and tool needed: Soft, clean cloth, 1/4" Allen wrench, Teflon
tape or plumber's dope

Due to the weight of the CIXX Shower Arm & Head assembly, it is necessary that it be installed piece-by-piece, according to the following instructions.

If you currently have a Sonoma Forge “temporary shower head” installed, proceed to Step 1. If you do not, please skip to Step 2.

Warning: Do Not Apply Heat – this will damage finish and void warranty.

Step 1: It is necessary to replace the entire shower head assembly when you receive your permanent system. The new CIXX Shower Arm has 2 set screws for a more secure installation.

Carefully remove your existing shower arm by backing out the set screw with an Allen wrench and gently pulling it free of the injector.



UPDATED
VERSION
JAN 2007

INSTALLATION INSTRUCTIONS C i X X SERIES – SHOWER HEAD

Step 2: Using one of the Allen wrenches provided, loosen (do not remove) the two set screws (top & bottom) on the shower arm.



Step 3: Apply plumber's grease if necessary, and carefully slide the new CIXX Shower Arm onto the injector in the wall. Make sure that it is properly seated then tighten the set screws by using the Allen wrench provided.

Step 4: Flush the lines.

Step 5: Loosen (do not remove) the two set screws on the sides of the new CIXX Shower Head. Using leather or other durable, non-abrasive material to protect the shower parts from your tools, unscrew the "ball-joint keeper" from the Head.





UPDATED
VERSION
JAN 2007

INSTALLATION INSTRUCTIONS C i X X SERIES – SHOWER HEAD

- Step 6:** Apply Teflon tape to the threads on the ball joint. Using a 1/4" Allen wrench (not provided), thread the ball joint into the shower arm until secure.



- Step 7:** Re-attach the CIXX Shower Head back on to the ball joint keeper, reversing the process in step 5. Remember to re-tighten the 2 set screws to secure the ball-joint & keeper.

- Step 8:** Adjust the head so the set screws are to either side when facing the shower head so you don't see them when in use.

