SONOMA SONOMA

INSTALLATION GUIDE

Strap Deck Mounted volume Control

May 2015

- Install the valve (1) through the deck, with the stem protruding 1-1/2" above the finished surface.
 NOTE: The Valve is shipped with 1 extra plastic Locking Nut (2) and Fiber Washer (3). Remove and discard the top nut.
- 2. In order to install the square Trim Flange (5) and the Lever Handle in the correct "off-position", it is necessary that the installer determine the closed valve position prior to installing the deck valves.
- 3. The process of alignment might take some trial and error. With the Trim Flange hand-tight, place escutcheon (9) on the valve to make sure that the handle will point in the desired direction. With 16 points of contact, you may need to turn the valve slightly to get the correct angle.
- 4. Install the bottom washer (6), locking nut (7), and then the top washer (8)

NOTE: The plastic washers must be installed as shown. These washers are produces to interact together, and replacements from other manufacturers may not function correctly.

- a. The bottom washer (6) has a thickness of ~1/8"
- b. The top Washer (8) has a thickness of ~1/16"
- 5. Place escutcheon (9) on top of valve stem, in the position desired. Use the screw (11) to secure in place.
- 6. Push handle **(10)** through larger hole in the escutcheon, locking the pins into the notches on the smaller opening. Screw on cap **(12)** tightly to back of handle, by hand.



