



UPDATED
VERSION
MAY 2008

PRODUCT INSTALLATION GUIDE

WATERBRIDGE LAV - WALL MOUNT (WB LAV WM)

**CHECK LOCAL CODES FOR CLEARANCE REQUIRED
BETWEEN BOTTOM OF SPOUT AND RIM OF VESSEL SINK**

- 1) Determine the desired height for the faucet and mark the wall.
- 2) Install the **mounting template** (pictured below), which is included with the faucet, securely in the wall. Use a level to ensure the supply lines will be at the same height.

NOTE: Additional studs and/or framing in the wall behind the template may be required for added support. There must be at least 1/2" between the template and finished wall.

- 3) Run 1/2" supply lines through the mounting template. Leave enough stubbed-out beyond the finished wall to properly attach the faucet.
- 4) Solder the supply lines to the template for rigidity.
- 5) Cap the lines until ready to install trim.

MOUNTING TEMPLATE FOR EXPOSED SHOWERS AND/OR WALL FAUCETS:





UPDATED
VERSION
MAY 2008

PRODUCT INSTALLATION GUIDE

WATERBRIDGE LAV - WALL MOUNT TRIM

- 6) Carefully slide the sleeves toward the face of the faucet, exposing the compression nuts. Remove the nuts, being careful not to lose the ferrules.
- 7) Slide the trim rings, compression nuts, threaded sleeves, then the ferrules, in that order, over the copper lines from Step #3.

NOTE: The threading on the sleeves is useless in this application.

FERRULE, THREADED SLEEVE, COMPRESSION NUT:



- 8) Supporting the faucet, tighten the compression nuts onto the back of the faucet. If the copper supply lines need to be trimmed, remove the faucet and return to step #7.
- 9) Gently slide the sleeves back over the compression nuts and against the trim rings.
- 10) Water test for leaks.